



Additional Fitting Instructions for MFK1220 Commodore v6 to LandCruiser Bundera

Thank you for purchasing a product manufactured by Marks 4WD Adaptors. The following instructions are intended as a guide. We recommend that you purchase a service manual pertaining to your vehicle for specific torque values, wiring diagrams and other related information.

The photos below are for the left-hand engine mount, the right hand mounting bracket supplied is bolted directly to the original Toyota rubber and chassis bracket.





Terms and Conditions

Thank you for purchasing this product manufactured by Marks 4WD Adaptors. Components supplied in this kit are designed and machined for a specific conversion only as outlined in this guide. Modifications to or substitution for any of the components without the written consent of Marks 4WD Adaptors will void any possible warranty or return privileges.

The following instructions are intended as a guide and only for Marks 4WD Adaptors kits. If you do not fully understand the steps, modifications or changes required to complete the conversion, contact our sales department for more information. We recommend that you purchase a service manual pertaining to your vehicle for specific torque values, wiring diagrams and other related information.

Contact Information

Web: <http://www.marks4wd.com/>
Email: sales@marks4wd.com
Phone: + 61 3 9552 6555
Address: 385-393 Lower Dandenong Rd
Dingley Victoria 3172
Australia