

06/05/11



Fitting instructions for

MFK1819 and MFK1819-LS1

Bracket Kits for

LS2 and LS1 Power Steering Reservoir and fitting to a Nissan 3ltr GU Patrol

Thank you for purchasing a product manufactured by Marks 4WD Adaptors. The following instructions are intended as a guide. It is recommended that you purchase a workshop manual to suit the model engine you are fitting.

1. Fit the LS2 power steering reservoir bracket supplied in the kit. Secure it using the original coil bracket stud and the two M6 x 16mm bolts supplied in the kit. See photo below:



2. Fit the LS1 power steering reservoir bracket supplied in the kit. Secure it using the original coil pack bolts. See photo below:



3. Cut the Commodore power steering reservoir bracket off the lifting bracket. If you do not have one you can purchase one from your local GM dealer, part number 92057323. Countersink the two holes and secure it to the bracket on the engine. See the photo on page one.
4. Fit the reservoir and hoses, use hose clamps on all hoses. **NOTE:** The supply and return hoses in the photo are GM ones. Our part number for the supply hose is MFK1819H and the return hose part number is 92194774. See photo below:



The components supplied in the kit are designed for specific type conversions. Modifications to any components without the written consent from Marks 4WD Adaptors will void any possible warranty or return privileges. Should you have any further questions that are not covered in the instruction sheet, please contact our sales department for assistance.

Proudly Manufactured by:

Marks 4WD Adaptors

385-393 Lower Dandenong Rd

Dingley Victoria 3172, Australia

Tel: (03) 9702 7366, Fax: (03) 9702 7566,

E-Mail: sales@marks4wd.com

Catalogue: <http://www.marks4wd.com/>