



Fitting Instruction for MFK1867 Heat Shield to suit 80 and 105 Series LandCruiser



Important Information

This instruction booklet can be used standalone for the above stated conversion but we would also recommend having a workshop manual for your Toyota LandCruiser vehicle to cover any factory torque / installation settings.

The instruction booklet describes the required modifications (if any) and installation process in order for our kit to fit and work properly.

Marks 4WD Adaptors cannot and will not take responsibility for knowing everything that may impact on your conversion. Before beginning any work, thoroughly work through the sequence of changes, work and potential impact of your conversion. You must ensure you completely understand all the factors that may impact on achieving your desired results.

Step 1 Fit Heat Shields

Fit the supplied heat shields as per the following photos.

You will need to drill and tap the extra holes required for mounting the shields.



Image 1.1 Fit heat shield



Image 1.2 Fit front engine mount/brake pipe heat shield

Terms and Conditions

Thank you for purchasing this product manufactured by Marks 4WD Adaptors. Components supplied in this kit are designed and machined for a specific conversion only as outlined in this guide. Modifications to or substitution for any of the components without the written consent of Marks 4WD Adaptors will void any possible warranty or return privileges.

The following instructions are intended as a guide and only for Marks 4WD Adaptors kits. If you do not fully understand the steps, modifications or changes required to complete the conversion, contact our sales department for more information. We recommend that you purchase a service manual pertaining to your vehicle for specific torque values, wiring diagrams and other related information.

Contact Information

Web: <http://www.marks4wd.com/>

Email: sales@marks4wd.com

Phone: + 61 3 9552 6555

Address: 385-393 Lower Dandenong Rd
Dingley Victoria 3172
Australia